

Replace a dying battery in your moneual RYDIS H68 Pro for a brand new one to allow for longer cleaning times.

INTRODUCTION


Battery running out fast? Follow this guide on how to change it for a new one.



TOOLS:


- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Battery



- Flip the vacuum over so that the wheels are facing you.
- Use a Phillips #1 screwdriver to remove the four 10mm screws that surround the battery cover.

Step 2



- Lift up the battery cover to reveal the battery.
- Remove the battery.

To reassemble your device, follow these instructions in reverse order.

